
Continuum Frame

2 Foot Extension Assembly Instructions

Table of Contents	i
Parts List	
Parts List	ii
Setup & Assembly	
Step 1: Disassembly	
Step 2: 2 Foot Table Installation	4
Step 3: Center Leg and Table Installation	5
Step 4: Middle Leg Brace Installation	6
Step 5: Track Assembly	7
Step 6: Track Assembly Installation	
Step7: Rail Assembly	10
Step 8: Rail Installation	11
Step 9: Rail Cap Installation	11


Parts List | 2 Foot Extension




Step 1 - Disassembly

Tools Needed:


3mm Allen Wrench 4mm Allen Wrench 5mm Allen Wrench




1-1 Remove all Rail Caps and set aside.




1-2 Remove all Rails and set aside.




1-3 Remove Track and set aside. **Note:** Repeat for the rear track.



1-4 Remove (8) Center Leg screws and set aside. **Note:** Remove (4) screws from the front and the rear so table sections can be separated.




1-6 Separate the Table Sections.




1-7 Remove one side of each rail assembly.

Step 2 - 2 Foot Table Installation


Parts Needed:







Tools Needed:


4mm Allen Wrench 5mm Allen Wrench



2-1 Remove Track Supports from 2 Foot Extension Table.








2-3 Secure using the (8) screws from step 1-4. **Note:** Leave all screws loose until step 4.


Step 3 - Middle Leg and Table Installation

Parts Needed:




Tools Needed:

4mm Allen Wrench 5mm Allen Wrench



3-1 Position the Table and Middle Leg.


Note: Adjust the height of the Middle Leg to match your existing setup.





3-2 Secure with (8) M8 x 16mm SBHCS.

Step 4 - Middle Leg Brace Assembly

Parts Needed:








4-1 Position Middle Leg Braces and secure with (12) M8 x 16mm SBHCS.

Note: Tighten all screws at this time.

Step 5 - Track Assembly

Parts Needed:




Plastic Track


Tools Needed:

4mm Allen Wrench






5-2 Remove one side of the Track Support from 5-3 Assemble Track Support Making sure there is your current configuration.



no gap between the Track Support Extrusions.




5-4 Install new 12 Foot Plastic Track.

Note: If you are adding the 2 Foot Extension to an 8 Foot Frame, you will need to cut the track with a saw. Do not bend the track to break it.


Step 6 - Track Assembly Installation

Parts Needed:



Tools Needed:

4mm Allen Wrench




6-1 Install front Track Assembly using (10) M6 x 10mm Connector Bolts.

Note: Repeat for rear Track Assembly. Align the Tracks as shown in the Continuum Frame Assembly Instructions.


Step 7 - Rail Assembly

Parts Needed:




Tools Needed:

4mm Allen Wrench



7-1 Assembly Rails as shown.

Note: If your system includes the 4th rail and/or idler rail accessories repeat step 7-1 for those rails. Idler rail 2 foot extension and coupler included with the idler rail.




8-1 Install extended rail assemblies into position.

Note: Assembly shown with 4th rail and idler rail accessories.

Step 9- Rail Cap Installation

Tools Needed:

3mm Allen Wrench



9-1 Install rail caps from step 1-1 on right and left sides.

The Grace Company 2225 South 3200 West Salt Lake City, UT 84119 Phone: 1-800-264-0644 www.graceframe.com

